



3間タイプ





盆踊りやぐら 3.0K  
コード 12011-30



2間半タイプ



盆踊りやぐら 2.5K  
コード 12011-25



1・2間タイプ



盆踊りやぐら 1.2K  
コード 12011-12

